



Installation guide

- 1.0 > Open the box remove glass & fixings, place in vertical position only and safely against a wall.
- 2.0 > Install hinges on the glass door, install bracket on the fixed panel glass & Install the bracket onto the top panel, **note: the fittings cannot contact the glass**, the Rubbers and plastic spacers must be fitted to the hinges and brackets to avoid the glass contacting the fittings.
- 3.0 > **(option 1 direct onto shower base)** Make sure that the walls and shower base are plumb.
(option 2 direct onto floor tiles) Make sure that the walls and tiles on the floor are plumb.
- 4.0 > Place fixed panel on to the wall, raise **3 mm** approximately from the Floor level that depends on your wall levels make sure it is plumb from all angles then mark out the bracket holes in correct position with a non staining pen .
- 4.1 > Remove the fixed panel, drill the holes in the correct position and install the fixed panel
- 5.0 > Place door on the wall adjust to correct position raise the door 5 to 10mm from the Floor level (depending on your floor or shower base and depending if you wish to use the clear seal) allow 2 to 3mm gap between the door and fixed panel, make sure it is plumb and you are satisfied with the gaps, mark out holes in correct position with Pencil or pen.
- 5.1 > remove the door, drill holes in the correct position and install the door.
- 6.0 > Place top panel in correct position make sure it is level mark out holes with pencil or pen.

- 6.1 > Drill holes in correct position and install.
- 7.0 > Silicone around the fixed panel floor and wall section & Silicone between top panel and fixed panel.
- 8.0 > Clean access silicone using a cloth and (mentholated spirit) or (wax and grease remover)
It is recommended that you allow 24 hrs for silicone to cure before using the shower.
- 9.0 > **You must retighten and readjust all hinges and fittings after two days of installation to allow for the rubber spacers to compact .**
- 10 > fit plastic strips to lower edge of the door or opening edge of the door ,
please note the plastic strips are optional according to the individuals taste and image of bathroom

This diagram is to be used as a guide only it does not include exact measurements as every floor and every wall is different as they all have different tolerances , the installer is responsible to take the glass measurements and calculating the figures prior to drilling and installing the glass , installer is responsible to comply with Australian Standard guidelines for installing glass and handling glass ..

If unsure about something email us : info@buildinggroup.com.au

(SAFETY INFORMATION)

IT IS VERY IMPORTANT THAT YOU READ AND UNDERSTAND THE FOLLOWING INSTRUCTION AND SAFETY NOTES BEFORE YOU BEGIN TO INSTALL THIS SHOWER SCREEN.

- > READ INSTALLATION INSTRUCTIONS
- > ALWAYS CHECK THAT THERE IS NO ELECTRICAL WIRES OR HOSES BEFORE YOU DRILL OR MOUNT ANYTHING.
- > **ALLWAYS WEAR SAFETY GLASSES.**
- > ALLWAYS WEAR GLOVES WHEN HANDLING CHEMICALS, SILCONE OR SUCH.
- > ALLWAYS HAVE ANOTHER PERSON TO HELP YOU IN THE INSTULLATION OF THIS SHOWER, IT IS HEAVY AND CAN CAUSE INJURY .
- > DO NOT DRILL ANY HOLES OR MOUNT ANYTHING UNLESS YOU ARE SURE THEY ARE IN THE CORRECT POSITION.
- > ALWAYS WORK IN A SAFE MANER & COMPLY WITH OHS REQUIRMENTS.
- > DO NOT STAND ON THE SHOWER SCREEN BOX OR ANY OTHER OBJECTS OR FIXINGS IT COULD CAUSE INJURY OR PHYSICAL HARM.
- > DO NOT LEAN ON THE GLASS OR USE IT TO SUPPORT YOU SELF OR ANYONE ELSE.
- > INCORRECT INSTALLATION MAY RESULT IN BREAKING THE SHOWER GLASS AND CAUSE PHYSICAL HARM AND INJURY.
- > DO NOT ALLOW CHILDREN TO USE THE SHOWER ALONE TO PREVENT INJURY.
- > DO NOT ALLOW CHILDREN TO PLAY OR SUCH IN THE SHOWER.
- > ENTER THE SHOWER SLOWLY WITH CARE TO AVOID SLIPPING, SOAP E.T.C... WILL MAKE IT VERY SLIPPERY.
- > DO NOT USE THE SHOWER IF YOU ARE UNDER MEDICATION OR UNDER INFLUENCE OF ALCOHOL OR SUCH THAT MAY CAUSE DROWSINESS OR OTHER RISKS.
- > DO NOT HANG OR PLACE ANYTHING ON ANY PARTS OF THE SHOWER.
- > DO NOT OVER TIGHTEN SCREWS OR PUT UNEVEN PRESSURE ON THE GLASS.
- > DO NOT CLEAN THE SHOWER GLASS OR FIXINGS WITH CHEMICAL SUCH AS ACID, ALKALINE SOLVENTS, SANDPAPER OR OTHER THAT WILL CAUSE DAMAGE.

This diagram supplied by us are to be used as a guide only , they do not include exact measurements as every floor and every wall is different as they all have different tolerances , the installer is responsible to take the glass measurements and calculating the figures prior to drilling and installing the glass , installer is responsible to comply with Australian Standard guidelines for installing glass and handling glass .. If unsure about something email us : info@buildinggroup.com.au